


Armrests


Armrest Bracket, stainless steel, flat, with accessories



- Hole spacing 130, 85 and 50 mm
- Easy attachment and adjustment using clamp supplied

E 1 4 011*	
A=	15,0 cm
B=	20,0 cm


Armrest Hardware Tube, T-Mounting



- Simple armrest hardware for fitting armrests to seat shells
- Easy attachment and adjustment using clamp supplied
- Hole spacing 100-205 mm

E 1 4 020*	
A=	35,0 cm
B=	24,0 cm


Armrest Hardware Tube, retractable



- Simple armrest holder with angle adjustable joint for fitting armrests to seat shells
- Easy attachment and adjustment using clamp supplied
- Hole spacing 100-205 mm

E 1 4 030=300 R/L*	
A=	30,0 cm
B=	24,0 cm


Armrest Hardware, retractable, with cone joint



- retractable
- with cone joint
- Hole spacing 100/61 mm

E 1 4 040 R/L*	
A=	40,0 cm
B=	15,0 cm


Armrest Hardware, with cone joint, mini



- stainless steel
- with cone joint
- Hole spacing 100/50 mm
- 10 mm square

E 1 4 050*	
A=	31,0 cm
B=	15,0 cm

Armrest Hardware, T-Mounting, mini




- stainless steel
- T-form
- Hole spacing 100/50 mm
- 10 mm square

E 1 4 060*	
A=	29,0 cm
B=	15,0 cm

Armrests

Armrest Hardware, stainless steel, with cone joint



- stainless steel
- with cone joint
- Hole spacing 100/63 mm

E 1 4 070=300R/L	
A=	34,0 cm
B=	16,0 cm